MICRODome


Surface Mount

What to Know


Risk of fire and electrical shock. Installation requires knowledge of electrical systems and should be installed by a qualified electrician. If not qualified, **DO NOT ATTEMPT INSTALLATION**.




Mark a line centered on the installation surface noting mounting clip locations



Secure the mounting clip to the mounting surface with appropriate hardware and snap fixture housing into clip




Join fixtures with quick connects, standard spacing between 0" and 8"



4

Locate and install the remote driver near the first fixture if installing multiple fixtures. Connect the quick connect cable from the first fixture to the Driver Box. (1) Driver Box can power 8-10ft of fixture depending on fixture specifications. Connect AC power to the driver. Refer to page 2 for wiring diagram.



Care Instructions:

Wipe with a soft cloth only. Always avoid using harsh chemicals and/or cleaners.




PAGE 1 OF 2

MICRODome

Wiring Diagram

XICO Driver Box



XICO Driver

