



## TBar


### What to Know

Risk of fire and electrical shock. Installation requires knowledge of electrical systems and should be installed by a qualified electrician. If not qualified, **DO NOT ATTEMPT INSTALLATION.**


- 1 Once the grid structure has been installed, engage the fixture into the desired location. Insert one end of the fixture at an angle and then the opposite end.




- 2 The fixture can be installed in line, replacing a Tbar or freely between Tbar locations. When installing in line, you may be required to fold over the Tbar fin, to allow clearance for the end cap.



- 3 If required, Tbar fins are included and can be installed anywhere along the fixture body to received a Tbar that runs perpendicular to the fixture.



- 4 An enclosed driver box is provided which is either fastened to the top of the fixture housing or installed remotely. Connect the fixture's Driver Box wires to the power source. Refer to the wiring diagram. Add structural supports as needed.



### Care Instructions:


Wipe with a soft cloth only. Always avoid using harsh chemicals and/or cleaners.

## TBar Additional Suspension


### What to Know

Risk of fire and electrical shock. Installation requires knowledge of electrical systems and should be installed by a qualified electrician. If not qualified, **DO NOT ATTEMPT INSTALLATION.**


- 1 Fit the 1/4-20 bolt through the Bracket and fasten the Bracket to the fixture housing with the provided 8-32 screws.



- 2 Thread the Cable Gripper onto the bracket and feed the Aircraft Cable through the Cable Gripper



- 3 Repeat on opposite side. Depending on the length of your fixture, a center suspension point may be needed.



- 4 Secure the other end of the aircraft cable to structure as needed.

### Care Instructions:


Wipe with a soft cloth only. Always avoid using harsh chemicals and/or cleaners.

**Continuous Run**


- 1** Place the 2 Fixtures on a flat and clean surface with the open ends facing each other. The joiner bracket will be pre-installed in one of the fixtures.




- 2** You may be required to loosen a screw to free up the joiner bracket.



- 3** Center the bracket between the 2 fixtures. Secure one side of the joiner to the fixture housing.



- 4** Pull the fixtures together and tighten the remaining screws.

**Care Instructions:**

Wipe with a soft cloth only. Always avoid using harsh chemicals and/or cleaners.

## Wiring Diagram

AC Power  
0-10V Dimming

